
















Model Savanna · Design by Jens Juul Eilersen

Arm height: 68 cm · Arm width: 20 cm · Total depth (frame): 100 cm · Seat depth: 57 cm · Seat height: 42 cm · Total height (frame): 68 cm

















	Sofa 220 x 100 cm		Centre section 220 x 100 cm		Chaiselong with arm 110 x 170 cm
	Sofa 230 x 100 cm		Closing section 120 x 100 cm		Chaiselong with arm 120 x 170 cm
	Sofa 240 x 100 cm		Closing section 130 x 100 cm		Chaiselong with arm 130 x 170 cm
	Corner section 108 x 108 cm		Closing section 140 x 100 cm		Chaiselong with arm 140 x 170 cm
	Centre section 100 x 100 cm		Closing section 150 x 100 cm		Chaiselong without arm 110 x 170 cm
	Centre section 110 x 100 cm		Closing section 160 x 100 cm		Chaiselong without arm 120 x 170 cm
	Centre section 120 x 100 cm		Closing section 170 x 100 cm		Chaiselong without arm 130 x 170 cm
	Centre section 130 x 100 cm		Closing section 180 x 100 cm		Chaiselong without arm 140 x 170 cm
	Centre section 140 x 100 cm		Closing section 190 x 100 cm		Footstool 60 x 100 cm
	Centre section 150 x 100 cm		Closing section 200 x 100 cm		Footstool 100 x 100 cm
	Centre section 160 x 100 cm		Closing section 210 x 100 cm		Footstool 100 x 150 cm
	Centre section 170 x 100 cm		Closing section 220 x 100 cm		
	Centre section 180 x 100 cm		Closing section 230 x 100 cm		
	Centre section 190 x 100 cm		Closing section 240 x 100 cm		
	Centre section 200 x 100 cm		Centre with short back 160 x 100 cm		
	Centre section 210 x 100 cm		Centre with short back 200 x 100 cm		





Model Savanna · Design by Jens Juul Eilersen










Arm height: 68 cm · Arm width: 20 cm · Total depth (frame): 100 cm · Seat depth: 57 cm · Seat height: 42 cm · Total height (frame): 68 cm

	Sofa 220 x 100 cm		Centre section 220 x 100 cm		Chaiselong with arm 110 x 170 cm
	Sofa 230 x 100 cm		Closing section 120 x 100 cm		Chaiselong with arm 120 x 170 cm
	Sofa 240 x 100 cm		Closing section 130 x 100 cm		Chaiselong with arm 130 x 170 cm
	Corner section 108 x 108 cm		Closing section 140 x 100 cm		Chaiselong with arm 140 x 170 cm
	Centre section 100 x 100 cm		Closing section 150 x 100 cm		Chaiselong without arm 110 x 170 cm
	Centre section 110 x 100 cm		Closing section 160 x 100 cm		Chaiselong without arm 120 x 170 cm
	Centre section 120 x 100 cm		Closing section 170 x 100 cm		Chaiselong without arm 130 x 170 cm
	Centre section 130 x 100 cm		Closing section 180 x 100 cm		Chaiselong without arm 140 x 170 cm
	Centre section 140 x 100 cm		Closing section 190 x 100 cm		Footstool 60 x 100 cm
	Centre section 150 x 100 cm		Closing section 200 x 100 cm		Footstool 100 x 100 cm
	Centre section 160 x 100 cm		Closing section 210 x 100 cm		Footstool 100 x 150 cm
	Centre section 170 x 100 cm		Closing section 220 x 100 cm		
	Centre section 180 x 100 cm		Closing section 230 x 100 cm		
	Centre section 190 x 100 cm		Closing section 240 x 100 cm		
	Centre section 200 x 100 cm		Centre with short back 160 x 100 cm		
	Centre section 210 x 100 cm		Centre with short back 200 x 100 cm		



Model Savanna · Design by Jens Juul Eilersen

Arm height: 26 3/4" · Arm width: 7 1/2" · Total depth (frame): 39 1/4" · Seat depth: 22 1/2" · Seat height: 16 1/2" · Total height (frame): 26 3/4"







	Sofa 86 1/2" x 39 1/4"		Center section 86 1/2" x 39 1/4"		Chaiselong with arm 43 1/4" x 67"
	Sofa 90 1/2" x 39 1/4"		Center section 47 1/4" x 39 1/4"		Chaiselong with arm 47 1/4" x 67"
	Sofa 94 1/2" x 39 1/4"		Center section 51 1/4" x 39 1/4"		Chaiselong with arm 51 1/4" x 67"
	Corner section 42 1/2" x 42 1/2"		Closing section 55" x 39 1/4"		Chaiselong with arm 55" x 67"
	Center section 39 1/4" x 39 1/4"		Closing section 59" x 39 1/4"		Chaiselong without arm 43 1/4" x 67"
	Center section 43 1/4" x 39 1/4"		Closing section 63" x 39 1/4"		Chaiselong without arm 47 1/4" x 67"
	Center section 47 1/4" x 39 1/4"		Closing section 67" x 39 1/4"		Chaiselong without arm 51 1/4" x 67"
	Center section 51 1/4" x 39 1/4"		Closing section 70 3/4" x 39 1/4"		Chaiselong without arm 55" x 67"
	Center section 55" x 39 1/4"		Closing section 74 3/4" x 39 1/4"		Footstool 60 x 39 1/4"
	Center section 59" x 39 1/4"		Closing section 82 3/4" x 39 1/4"		Footstool 39 1/4" x 39 1/4"
	Center section 63" x 39 1/4"		Closing section 86 1/2" x 39 1/4"		Footstool 39 1/4" x 59"
	Center section 67" x 39 1/4"		Closing section 90 1/2" x 39 1/4"		
	Center section 70 3/4" x 39 1/4"		Closing section 90 1/2" x 39 1/4"		
	Center section 74 3/4" x 39 1/4"		Closing section 94 1/2" x 39 1/4"		
	Center section 78 3/4" x 39 1/4"		Center with short back 63" x 39 1/4"		
	Center section 82 3/4" x 39 1/4"		Center with short back 78 3/4" x 39 1/4"		





Model Savanna · Design by Jens Juul Eilersen

Arm height: 26 ¾" · Arm width: 7 ½" · Total depth (frame): 39 ¼" · Seat depth: 22 ½" · Seat height: 16 ½" · Total height (frame): 26 ¾"

	Sofa 86 ½" x 39 ¼"		Center section 86 ½" x 39 ¼"		Chaiselong with arm 43 ¼" x 67"
	Sofa 90 ½" x 39 ¼"		Center section 47 ¼" x 39 ¼"		Chaiselong with arm 47 ¼" x 67"
	Sofa 94 ½" x 39 ¼"		Center section 51 ¼" x 39 ¼"		Chaiselong with arm 51 ¼" x 67"
	Corner section 42 ½" x 42 ½"		Closing section 55" x 39 ¼"		Chaiselong with arm 55" x 67"
	Center section 39 ¼" x 39 ¼"		Closing section 59" x 39 ¼"		Chaiselong without arm 43 ¼" x 67"
	Center section 43 ¼" x 39 ¼"		Closing section 63" x 39 ¼"		Chaiselong without arm 47 ¼" x 67"
	Center section 47 ¼" x 39 ¼"		Closing section 67" x 39 ¼"		Chaiselong without arm 51 ¼" x 67"
	Center section 51 ¼" x 39 ¼"		Closing section 70 ¾" x 39 ¼"		Chaiselong without arm 55" x 67"
	Center section 55" x 39 ¼"		Closing section 74 ¾" x 39 ¼"		Footstool 60 x 39 ¼"
	Center section 59" x 39 ¼"		Closing section 78 ¾" x 39 ¼"		Footstool 39 ¼" x 39 ¼"
	Center section 63" x 39 ¼"		Closing section 82 ¾" x 39 ¼"		Footstool 39 ¼" x 59"
	Center section 67" x 39 ¼"		Closing section 86 ½" x 39 ¼"		
	Center section 70 ¾" x 39 ¼"		Closing section 90 ½" x 39 ¼"		
	Center section 74 ¾" x 39 ¼"		Center with short back 63" x 39 ¼"		
	Center section 78 ¾" x 39 ¼"		Center with short back 78 ¾" x 39 ¼"		
	Center section 82 ¾" x 39 ¼"				