



Model Cocoon · Design by Jens Juul Eilersen


Arm height (frame): 73 cm · Arm width: 7 cm · Total depth (frame): 106 cm · Seat depth: 53 cm · Seat height: 36 cm · Total height (frame): 73 cm



Corner section  
106 x 106 cm



Centre section  
100 x 106 cm



Closing section  
110 x 106 cm



Closing section  
120 x 106 cm



Closing section  
130 x 106 cm



Closing section  
140 x 106 cm



Chaiselong  
120 x 166 cm



Footstool  
120 x 60 cm

Scale 1:100

All overall dimensions correspond to frame sizes.

**eilersen**<sup>®</sup>  
since 1895



Model Cocoon · Design by Jens Juul Eilersen


Arm height (frame): 73 cm · Arm width: 7 cm · Total depth (frame): 106 cm · Seat depth: 53 cm · Seat height: 36 cm · Total height (frame): 73 cm



Corner section  
106 x 106 cm



Centre section  
100 x 106 cm




Closing section  
110 x 106 cm



Closing section  
120 x 106 cm




Closing section  
130 x 106 cm



Closing section  
140 x 106 cm



Chaiselong  
120 x 166 cm



Footstool  
120 x 60 cm

Scale 1:100

All overall dimensions correspond to frame sizes.

  
**eilersen**<sup>®</sup>  
since 1895



Model Cocoon · Design by Jens Juul Eilersen

Arm height (frame): 28  $\frac{3}{4}$ " · Arm width: 2  $\frac{3}{4}$ " · Total depth (frame): 41  $\frac{3}{4}$ " · Seat depth: 22  $\frac{3}{4}$ " · Seat depth: 14  $\frac{1}{4}$ " · Total height (frame): 28  $\frac{3}{4}$ "



Corner section  
41  $\frac{3}{4}$ " x 41  $\frac{3}{4}$ "



Centre section  
39  $\frac{1}{4}$ " x 41  $\frac{3}{4}$ "



Closing section  
43  $\frac{1}{4}$ " x 41  $\frac{3}{4}$ "




Closing section  
47  $\frac{1}{4}$ " x 41  $\frac{3}{4}$ "



Closing section  
51  $\frac{1}{4}$ " x 41  $\frac{3}{4}$ "



Closing section  
55" x 41  $\frac{3}{4}$ "



Chaiselong  
47  $\frac{1}{4}$ " x 65  $\frac{1}{4}$ "



Footstool  
47  $\frac{1}{4}$ " x 23  $\frac{1}{2}$ "

Scale 1:100

All overall dimensions correspond to frame sizes.

**eilersen**<sup>®</sup>  
since 1895



Model Cocoon · Design by Jens Juul Eilersen


Arm height (frame): 28  $\frac{3}{4}$ " · Arm width: 2  $\frac{3}{4}$ " · Total depth (frame): 41  $\frac{3}{4}$ " · Seat depth: 22  $\frac{3}{4}$ " · Seat depth: 14  $\frac{1}{4}$ " · Total height (frame): 28  $\frac{3}{4}$ "



Corner section  
41  $\frac{3}{4}$ " x 41  $\frac{3}{4}$ "




Centre section  
39  $\frac{1}{4}$ " x 41  $\frac{3}{4}$ "




Closing section  
43  $\frac{1}{4}$ " x 41  $\frac{3}{4}$ "



Closing section  
47  $\frac{1}{4}$ " x 41  $\frac{3}{4}$ "



Closing section  
51  $\frac{1}{4}$ " x 41  $\frac{3}{4}$ "



Closing section  
55" x 41  $\frac{3}{4}$ "



Chaiselong  
47  $\frac{1}{4}$ " x 65  $\frac{1}{4}$ "



Footstool  
47  $\frac{1}{4}$ " x 23  $\frac{1}{2}$ "

Scale 1:100

All overall dimensions correspond to frame sizes.

  
**eilersen**<sup>®</sup>  
since 1895



## Model Cocoon · Design by Jens Juul Eilersen

English:

Cocoon is inspired by the pupa stage of the silkworm. You can go into a cocoon of cushions with 100% individual and flexible levels of comfort. Individualism and diversity have been demanded for many years. Some people want to float. Others want to sit. A sofa is often either-or, but not Cocoon. Here is a cornucopia of both worlds. In your safe and solid cocoon frame you have a gigantic toy box with triangular cushions, lumbar bolsters, main cushions, armrests, neck bolsters – in fact, cushions of all sizes and shapes. This method allows you to determine the degree of comfort yourself, and at the same time be able to have great fun building and being in the sofa. Cocoon supports you all the way round. Primarily with its high back, but also the seats, which feature Eilersen's renowned down top, giving both firmness and softness at the same time. Here's a little recommendation for you when you design your Cocoon: buy cushions and elements in different fabric design when you choose your sofa's style. That will give you a truly unique cocoon.

Dansk:

Cocoon er inspireret af silkesommerfuglens puppe. Her kan du forpuppe dig i et pudeunivers med 100% individuelt og fleksibelt niveau af komfort. Individualisme og mangfoldighed har været efterspurgt i mange år. Nogle vil flyde. Andre vil sidde. Ofte er en sofa enten-eller, men sådan er det ikke med Cocoon. Her får du et overflødighedshorn af både-og. I dit trygge og solide pubbehylster har du en gigantisk legetøjskasse med trekantede pudser, lændepøller, hovedpuder, armstøtter, nakkepøller – ja pudser i alskens størrelser og former. På den måde bestemmer du selv graden af bekvemmelighed og komfort, og samtidig kan du have det sjovt både med at bygge og være i sofaen.

Cocoon giver dig støtte hele vejen rundt. Først og fremmest med sin høje ryg, men også via sæderne, der er Eilersens velkendte dunstop og derfor giver spændstighed og blødhed på samme tid. Tip til en ekstra streng at spille på, når du designer din Cocoon: Køb pudser og elementer i forskellige stofdesigns, når du styler din sofa. Så får du en helt unik puppe.