# **BRICK MODULAR SOFA**

Brick is a minimalistic and timeless sofa, with deep seats for a comfortable lounge feel. Using the wide range of modules, the sofa can be fully customised to fit any space big or small.



LEFT / RIGHT MODULE

Width: 117 cm Depth: 105 cm Back Height: 73 cm Seat Height: 42 cm Seat Depth: 70 cm



# CORNER MODULE

Width: 104 cm Depth: 104 cm Back Height: 73 cm Seat Height: 42 cm Seat Depth: 70 cm



# MIDDLE MODULE

Width: 94 cm Depth: 105 cm Back Height: 73 cm Seat Height: 42 cm Seat Depth: 70 cm



# LEFT / RIGHT OPEN END MODULE

Width: 140 cm Depth: 105 cm Back Height: 73 cm Seat Height: 42 cm Seat Depth: 70 cm



# LEFT / RIGHT CHAISE LOUNGE MODULE

Width: 117 cm Depth: 140 cm Back Height: 73 cm Seat Height: 42 cm Seat Depth: 105 cm



# **CONFIGURATION EXAMPLES**



2-SEATER Left Module x1 / Right Module x1

2-SEATER OPEN END Left Module x1 / Right Open End Module x1



2-SEATER CHAISE LOUNGE OPEN END Left Chaise Lounge Module x1 / Right Open End Module x1



**3-SEATER** Left Module x1 / Middle Module x1 / Right Module x1



3-SEATER CHAISE LOUNGE OPEN END Left Chaise Lounge Module x1 / Middle Module x1 / Right Open End Module x1



5-SEATER CORNER Left Module x1 / Middle Module x2 / Corner Module x1 / Right Module x1



4-SEATER CORNER OPEN END Left Open End Module x1 / Corner Module x1 / Middle Module x1 / Right Module x1







Place the individual modules side by side with a 30-40 cm distance.



# STEP 2

Grab the two hooks which are fastened underneath the sofa-module and pull them gently out (90 degrees) until you hear a 'click'.





#### STEP 3

When both hooks have been placed in position, the elements are gently pushed together while you make sure the hooks catch the corresponding bracket.

## STEP 4

Keep pushing until the modules touch each other without any visual gap. Now the modules will be firmly locked against each other.

# STEP 5

In order to disassemble the modules again you will need to gently lift the module with the "small nail connecter" to release the locking mechanism again.





## STEP 1

Shake and cuff the seat-, back- and loose cushions regularly to ensure the fillings regain the intended structure and shape and to make sure the seams stay even.



### STEP 2

Sometimes the surface of the fabric can form small 'balls' of entangled textile fibres. This is called pilling and can happen for several reasons including extraneous fibres from clothing, blankets and dust which get stuck on the surface of the fabric. Pilling can easily be removed with an electric fabric-pill remover.



### STEP 3

All upholstered furnitures benefit from proper maintenance. This means you should vacuum your furniture once a week to pick up any loose dirt and dust. We also recommend that you occasionally wipe the fabric with a damp cloth, so that the fibrers can retain elasticity and the fabric maintains its attractive appearance for longer. It is also important that you remove any stains and dirt as soon as possible.



## STEP 4

Grease stains can be removed with a stain remover. Use of stain removers is at your own risk. If you choose to use a stain remover, we recommend that you:

- a. Use a soft white cloth.
- b. Test it on a none-visible area first to see if the colour disappears.
- c. Treat the stain from the outer edges inward, in order to avoid streaks.
- d. Wipe the entire area with a damp cloth when the stain has been removed.
- e. Always use professional furniture cleaner for removing difficult stains.